



Partno.	Description	Partno.	Description	Partno.	Description
500	Flush hose	513.B	ABS seat bayonet bowl	529**	Piston ring
501	Complete pump	514	Handle, white or red	531.1	Bayonet base sparepart
502	Pump housing	516**	Inlet valve	531.2	Bayonet top sparepart
503	Base	517**	Outlet valve	531.3	Bayonet cover
504	Valve cover	518**	Check valve	534.1	O-ring bayonet bowl
505	Discharge elbow	519	Piston house	534.2	O-ring bayonet to base
506	Discharge flange	520	Drain plug	535	O-ring
507	Lever	523	Pump to base bolts (set)	536	Boltset elbow
508	Flipper	524	Valve housing screws (set)	530**	Repairkit
509	Piston shaft	525	Bumper washer		
511	Bowl ABS Bayonet	526	Valve plate		
511.8	Hinges ABS Seat	527**	Shaft seal		
511.10	Screw set bayonet base	528	Piston rod with piston		